

ACCESSORIES

AXGT

Split Core Remote with Terminals, Replacement for Any Damaged or Lost Sensor



SPECIFICATIONS

Only For Use With	RIBXJA, RIBXJF, RIBXLCJA, RIBXLCJF, RIBXLSJA, RIBXLSJF Can replace any damaged or lost sensor
Purpose	For use with the models listed above
Dimensions	(Inside) .52" x .52" (Outside) 2.52" x 2.00" x 1.75"
Origin	Made of US and non-US parts

